








ESK/EFK Covers For Pilot Lights, Push Buttons, or Selector Switches For EFD Bodies

Covers Only — for use on standard EFD bodies

Supplied with 4 cover bolts and blank cover nameplate.

| | | Description | Catalog Number |
|--|---|---|--------------------|
| Push Button or Pilot Light Covers — 3/4" Tapped Openings * | | | |
|  |  | One opening: one push button or one pilot light | ESKB-1PBQ |
| ESKB-1PBQ | ESKB-2PBQ | Two openings: two push buttons, two pilot lights, or one of each | ESKB-2PBQ |
|  | | Three openings: three device (EFDL) three push buttons or three pilot lights, or combination of push button(s) and pilot light(s) | EFKL-3HQ † |
| EFKL-3HQ | | | |
| Push Button or Selector Switch Cover — 1/2" Tapped Openings * | | | |
|  | | Two openings: selector switch or two push buttons | ESKB-2SPQ |
| Push Button, Pilot Light or Selector Switch Covers — 3/4" top and 1/2" Bottom Tapped Openings * | | | |
|  |  | One top and two bottom openings: one pilot light, two push buttons; one pilot light, one selector switch. | ESKB-3JPBQ |
| ESKB-3JPBQ | ESKB-BQ | Blank | ESKB-BQ |
| Nameplate Mounting Bracket | | | |
|  | | Bracket with blank silver/black nameplate for EFDB series | NPBRKT-EFDB |
| | | Bracket with blank silver/black nameplate for 3-device EFD series | NPBRKT-CONT |
| | | To order bracket with control station, add suffix -NPBRKT to end of catalog number. | |
| | | To order engraved nameplates, add desired markings after catalog number. Maximum of 2 lines with 12 characters (including spaces) per line. | |
| | | <i>Note: Mount bracket between cover screws and cover. Do not mount bracket between ground joint flame path between cover and backbox.</i> | |

* All covers are copperfree aluminum. Supplied with four captive stainless steel bolts.

† Catalog number EFKL-3HQ supplied with 6 stainless steel non-captive bolts.