

Lug kits and accessories

Standard main/sub-feed breaker lug capacities

Ampere rating	Lug wire range Al/Cu
100	(1) #14–1/0
125–225	(1) #4–4/0
250–350	(1) 250–500 kcmil
400	(2) 3/0–250 kcmil or (1) 3/0–500 kcmil

Main/through-feed lug kits

Ampere rating	Wire range Al/Cu	Catalog number
100	(1) #14–1/0	LUGKIT100
225	(1) #6–300 kcmil	LUGKIT225
400	(2) #2–500 kcmil	LUGKIT400
600	(2) #2–500 kcmil	LUGKIT600

Kits

Description	Catalog number		
	100 A	225 A	400/600 A
Service entrance kit	SEK1/2	SEK1.2	SEK4/6
200% neutral kit	2NK100	2NK225	1NK400
Sub-feed breaker adapter (used to mount 225 A sub-feed breaker in 400 A panels)	—	—	225ASFBKIT
Sub-feed breaker adapter (used to mount 225 A sub-feed breaker in 600 A panels)	—	—	225BSFBKIT
Sub-feed breaker adapter (used to mount 400 A sub-feed breaker in 600 A panels)	—	—	400ASFBKIT

Accessories

Description	Catalog number
Isolated ground bar kit	ISOGROUND
Copper ground bar kit	CUGROUND
1P filler plate ❶	5155C62H01
Series rating kit ❷	SRK

❶ Each PRS panel comes with 50% filler plates, e.g., 18 circuit interior contains 9 filler plates.

❷ Series rating kit includes series rating book and adhesive sleeve and series rating sticker. If panelboard is being series rated higher than the base rating, an SRK is required.