

Accessories

Auxiliary Contacts

Side-Mount Auxiliary Contacts



Can be fitted on the right side of manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT) and can be combined with XTPAXSATR... and XTPAXFA... trip indicating auxiliary contact.

Table 34-183. Side-Mount Auxiliary Contacts

| Contact Configuration | Contact Sequence | Screw Terminals | | Spring Cage Terminals | | Price U.S. \$ ① |
|-----------------------|------------------|-----------------|----------------|-----------------------|----------------|-----------------|
| | | Pkg. Qty. | Catalog Number | Pkg. Qty. | Catalog Number | |
| 1NO-1NC | | 5 | XTPAXSA11 | 5 | XTPAXSAC11 | |
| 1NO-2NC | | 5 | XTPAXSA12 | — | — | |
| 2NO-1NC | | 5 | XTPAXSA21 | — | — | |

① Orders must be placed in multiples of package quantity listed.

Front-Mount Auxiliary Contacts



Can be fitted to manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT). 45 mm (XTPR...B and XTPB) or 55 mm (XTPR...D) widths of manual motor protectors remain unchanged.

Table 34-184. Front-Mount Auxiliary Contacts

| Contact Configuration | Contact Sequence | Screw Terminals | | Spring Cage Terminals | | Price U.S. \$ ② |
|-----------------------|------------------|-----------------|----------------|-----------------------|----------------|-----------------|
| | | Pkg. Qty. | Catalog Number | Pkg. Qty. | Catalog Number | |
| 1NO-1NC | | 5 | XTPAXFA11 | — | — | |
| 1NO-0NC | | 5 | XTPAXFA10 | 5 | XTPAXFAC10 | |
| 0NO-1NC | | — | — | 5 | XTPAXFAC01 | |

② Orders must be placed in multiples of package quantity listed.

Discount Symbol 1CD7