






## Electrical Accessories Fluorescent Starters & Wall Plate Inserts

Fluorescent Starters				
	Catalog Number	Description	UL	CSA
 <p>FS2 FS4 FS5 FS25</p>	FS2	Glow switch starter without reset, 2 pins 14, 15 & 20W.	•	•
	FS4	Glow switch starter without reset, 2 pins 13, 30 & 40W.	•	•
	FS5	Glow switch starter without reset, 2 pins 4, 6 & 8W.	•	•
	FS25	Glow switch starter without reset, 2 pins 22W Circline 25W Std.	•	•
Wall Plate Inserts				
Dimensions	Catalog Number	Description	Finish	Color
	<b>325I</b> <b>325W</b> <b>325</b> <b>325BK</b> <b>325LA</b> <b>325GRY</b>	Mounting strap for blank insert. Box mounted. Changes decorator opening to blank.	Polycarbonate Plastic	Ivory White Brown Black Light Almond Grey
	<b>326I</b> <b>326W</b> <b>326</b> <b>326LA</b>	Mounting strap for blank insert. Box mounted. Changes decorator opening to blank.	Painted Steel	Ivory White Brown Light Almond
	<b>327I</b> <b>327W</b> <b>327</b> <b>327LA</b>	Mounting strap for dimmer insert. Box mounted. Change from decorator to toggle opening.	Painted Steel	Ivory White Brown Light Almond
	<b>80700I</b> <b>80700W</b> <b>80700LA</b>	Mounting strap for blank insert. Box mounted. Changes toggle opening to blank.	Thermoset Plastic	Ivory White Light Almond