


44

Safety Socket & T-Fuse Replacement

COMMERCIAL
METERING
SAFETY SOCKET
& T-FUSE
REPLACEMENT



MS-27-TB



TB200-47

Tenant Meter Sockets


| Catalog Number | amp | Voltage / System |
|----------------|-----|------------------|
| MS-24-TB | 200 | 600V / 1Ø3W |
| MS-25-TB | 200 | 600V / 3Ø3W |
| MS-27-TB | 200 | 600V / 3Ø4W |

Replacement Test Blocks

| Catalog Number | amp | Phase |
|------------------------------|-----|--------------------|
| TB100-47 | 100 | Phase A, B & C |
| TB100-5 Center Block Only | 100 | Phase B – 3Ø3W |
| TB200-47 | 200 | Phase A, B & C |
| TB200-5 Center Block Only | 200 | Phase B – 3Ø3W |
| TB200-LL | 200 | Lug – Lug |
| TB-BARR #Z707371-MO | — | Test Block Barrier |



PT324



240 Volt Main Disconnects Pullout Switch (Uses Type "T" Fuse)

| Catalog Number | amp | Rating |
|----------------|-----|-------------------|
| PT223 | 100 | 2 Pole – 240 Volt |
| PT224 | 200 | 2 Pole – 240 Volt |
| PT323 | 100 | 3 Pole – 240 Volt |
| PT324 | 200 | 3 Pole – 240 Volt |

480 Volt Main Disconnects Pullout Switch (Uses Type "T" Fuse)

| Catalog Number | amp | Rating |
|----------------|-----|-------------------|
| PT263 | 100 | 2 Pole – 480 Volt |
| PT264 | 200 | 2 Pole – 480 Volt |
| PT363 | 100 | 3 Pole – 480 Volt |
| PT364 | 200 | 3 Pole – 480 Volt |

*These UL Listed products are for use in areas requiring
Electrical Utility Service Equipment Requirements Committee (EUSERC) compliance.*



Utility requirements for this equipment may vary. Always consult the serving utility for their requirements prior to ordering or installing this equipment. This product must be installed by a licensed electrician. Installation of this equipment may require local electrical inspector approval.