



Recessed Indoor IN BOX™ for New & Retrofit Construction

New!


Non-metallic, recessed electrical box with trim plate. For power or low voltage.

CATALOG NUMBER	UPC/DCI/NAED MFG #01 8997	DESCRIPTION / CU.IN.	UNIT PKG	STD PKG	DIM A	DIM B	DIM C
DVFR3W	14340	3-Gang, White / 49.3	1	1	7.930	6.818	3.8
DVFR3BL	14341	3-Gang, Black / 49.3	1	1	7.930	6.818	3.875
DVFR4W	14342	4-Gang, White / 64.5	1	1	9.742	6.818	3.875
DVFR4BL	14343	4-Gang, Black / 64.5	1	1	9.742	6.818	3.875

Add suffix "GC" to Catalog # when ordering in Canada, for example DVFR3WGC. Includes Voltage Separator for power and/or low voltage. PATENTED. ADDITIONAL PATENTS PENDING.



E170558 LR49636



DVFR3W



DVFR4W

Indoor IN BOX includes... Recessed box & trim plate; **DVFR1:** (1) standard duplex & (1) standard GFCI face plate; **DVFR2:** (1) standard GFCI face plate & (1) low voltage separator; **DVFR1/DVFR2:** (2) mounting screws, (2) trim plate installation screws, & (1) NM94 (1/2"); **DVFR3/DVFR4:** (2) mounting screws, (4) trim plate installation screws, (2) NM94 (1/2"), (1) NM95 (3/4"), (1) decorator style wall plate, & (1) low voltage separator.

Installation Instructions - New Work (DVFR4W shown)

For a video installation demonstration visit our website @ aifittings.com



1 Mount box to stud. Use tabs for proper positioning of box for 1/2" wall finish. See Photo A.



Positioning tabs



2 Attach paintable trim plate with screws provided.

OPTIONAL for new work
Tighten mounting wing screws for added box stability. See Photo B below.

Features and Benefits

- Recessed, indoor box allows flat screen TVs, furniture, and countertop items to be mounted or placed flush against the wall
- Plugs and/or connectors don't extend past the wall
- Trim plate is textured/paintable and covers edges of cut wall surface
- Mounting wings hold bracket securely against wall when screws are tightened
- Tab guides provided for proper positioning of box on stud for 1/2" or 5/8" drywall


Retrofit Work (DVFR3W shown)



1 Using box, without trim plate as a template, mark location. Cut hole. Attach trim plate to box with supplied screws. Pull wire(s). Insert box into hole.



2 Tighten mounting wing screws to pull the box securely against the wall board (up to 1-1/2"). See Photo B at right. Insert voltage separator if installing power and low voltage Class 2 wiring.



Trim plate screws Mounting wing screws